



1: Power:




Headset power button (short press)

Comhub power button (long press)




2: Battery Level:



3: Charging:

Always close and latch for storage.



Red headsets:
Wing Walker



Blue headset:
Tractor Driver

4: Connect to an aircraft:



Aircraft intercom cable connector (tighten using your Sonetics screwdriver)

All ground crew communicate hands-free via the intercom.

The tractor driver can communicate with the flight deck by using the push to talk buttons on either side of the headset.

Wing walkers cannot talk to the flight deck.

All ground crew can hear the flight deck.

5: Basic features - controls

To access the Advanced Menu, press both push to talk buttons at the same time.

