

## Wireless Headset-to-Base-Station Pairing Procedure

Link a Wireless Base Station to a Wireless Headset

rev. 08-28-15

### NOTE: To pair additional headsets

If you need to pair additional headsets to the system, be sure to leave any previously linked headsets **ON** while you link the additional units.

### PROCEDURE

1. Press and hold the pairing button on the front panel of the base station for approximately 5-7 seconds until the YELLOW LED(s) on the front panel of the base station begin flashing slowly. This indicates that the base station has entered pairing mode. Once the base station is placed in pairing mode, the user has approximately 15 seconds to place the headset in pairing mode.
2. Press and hold the PTT button while you turn headset power ON. After approximately 5 seconds, the GREEN and RED LEDs on the outside of the left ear dome will start flashing in a relatively fast alternating pattern. Release the PTT button.
3. Monitor the GREEN and RED LEDs on the left ear dome of the headset. After about 5-7 seconds, the alternating flashing pattern will end and the GREEN LED will go to steady illumination to indicate that the headset is paired and linked to the base station.
4. The respective LINK LED on the base station will illuminate steadily to indicate that a link to the headset has been established.
5. Repeat steps 1 through 4 for each additional headset.

### CONTACT FLIGHTCOM SERVICE

Monday–Friday, 6:30am–5:00pm Pacific  
(503) 684-6647 | [service@flightcom.net](mailto:service@flightcom.net)



For ComCare Customers, call 1-855-392-6622.

For additional information, visit us at [www.flightcom.net/service-and-support](http://www.flightcom.net/service-and-support)

### FLIGHTCOM

7340 SW Durham Rd. | Portland, OR 97224 USA | 800-432-4342 • 503-684-8229 | fax: 503-620-2943 | [www.flightcom.net](http://www.flightcom.net)