





APX379 ELECTRONIC HEADSET Quick Start Guide




BASIC FEATURES – CONTROLS




STATUS LED FUNCTIONALITY

Battery level and connection status are both shown with the status LED.



Battery Level

Number of pulses indicates battery charge level.



LED color will vary depending on connection type.

Charge Status


When plugged in, the color of the LED indicates charge state. Slow flashing indicates a charge fault.



NEW BLUETOOTH PAIRING

- 1: Turn off headset.
- 2: Turn on headset.
- 3: Headset enters Bluetooth pairing mode.






4: On phone, search for "Sonetics-HS-XX".

Password is "0000".

BLUETOOTH USE

Answer Call		Press left PTT button.
End Call	→	Press left PTT button.

MIC POSITIONING



Position mic no more than 1/8" from lips.


DECT PAIRING

For first use:

1: Place Base Station into pairing mode (see base station manual for details).



2: Push and hold Push To talk and Power until status LED flashes red and green. 3: The status LED flashes green when connection is successful. If it does not, repeat the pairing process.



Complete manual available at soneticscorp.com/support



www.soneticscorp.com

800-833-4558

17600 SW 65TH Ave Lake Oswego, OR 97035 USA

© 2019 Sonetics Corporation. All Rights Reserved. The information in this document is subject to change without notice. No part of this document may be copied or reproduced in any form without the prior written consent of Sonetics Corporation.

600-3052-00 Rev E