

POWERING ON/OFF

Press and release the power button. Turn off the ComHub and headsets when not in use.

Turn the ComHub off first and then the headsets to prevent false alarms from the Pilot Alert system.



BATTERY INDICATORS

Headset:

- Charging
- Fully Charged



1 flash	☼	25%
2 flashes	☼ ☼	50%
3 flashes	☼ ☼ ☼	75%
4 flashes	☼ ☼ ☼ ☼	100%

LED color depends on connection type.

ComHub:



☼ ON	● CHARGING
● OFF	● CHARGED

1 flash	☼	25%
2 flashes	☼ ☼	50%
3 flashes	☼ ☼ ☼	75%
4 flashes	☼ ☼ ☼ ☼	100%

CHARGING the SYSTEM

Plug each headset and the ComHub into the yellow charging cables inside the case.

Plug the power adapter into the case's charging connector near the carry handle.



IMPORTANT: Place headsets in case when not in use. Keep lid latched and closed.

COMHUB TO AIRCRAFT



BLUE vs. RED



BLUE
TRACTOR OPERATOR





Press PTT to talk to the flight deck.



RED
WING WALKERS

PTT not required.

COMM CABLE TIPS

-  **DO** make sure the connector is fully seated (hear 3 'clicks');
-  **DO** insert and remove the plug without bending it;
-  **DON'T** remove the plug by pulling on the cord;
-  **DON'T** drag the tip of the cable on the ground.



HEADSET VOLUME

The plus (“+”) and minus (“-”) soft buttons on the left ear dome (with the mic boom) control headset volume UP and DOWN.



PILOT ALERT!

If all headsets disconnect, go out of range, or are all turned off during a pushback, a Pilot Alert tone will be sent from the ComHub to the flight deck.

The tone is a 2-step alternating tone. Reconnect the Tractor Operator headset or cycle power at the ComHub to reset the Pilot Alert tone.



For technical support, call or visit:

1.855.392.6622 | flightcom.net/support

7340 SW Durham Road | Portland, OR 97224 USA | service@flightcom.net